#### **Okonite Cables** Facilities Overview

Atlanta District Office

#### **District Offices, Manufacturing Plants & Service Centers**



Orangeburg, SC - Manufacturing Plant ourg, SC - Compound Facility



Santa Maria, CA - Manufacturing Plant



Cumberland, RI - Manufacturing Plant



Paterson, NJ - Manufacturing Plant

(770) 928-9778 FAX: (770) 928-0913 F-Mail: atlanta@okonite.com Birmingham District Office (205) 655-0390 FAX: (205) 655-0393 E-Mail: birmingham@okonite.com **Boston District Office** (603) 625-1900 (781) 749-3374 FAX: (603) 624-2252 E-Mail: boston@okonite.com Charlotte District Office (704) 542-1572 FAX: (704) 541-6183 E-Mail: charlotte@okonite.com Chicago District Office (630) 961-3100 FAX: (630) 961-3273 E-Mail: chicago@okonite.com Cincinnati District Office (513) 771-2122 FAX: (513) 771-2126 E-Mail: cincinnati@okonite.com **Cleveland District Office** (330) 926-9181 FAX: (330) 926-9183 E-Mail: cleveland@okonite.com **Dallas District Office** (940) 383-1967 FAX: (940) 383-8447 E-Mail: dallas@okonite.com **Denver District Office** (303) 772-3517 FAX: (303) 255-3513 E-Mail: denver@okonite.com Hartford District Office (860) 258-1900 FAX: (860) 258-1903 E-Mail: hartford@okonite.com Houston District Office & Service Center (281) 821-5500 FAX: (281) 821-7855 E-Mail: houston@okonite.com Kansas City District Office & Service Center (913) 422-6958 FAX: (913) 422-1647 E-Mail: kansascity@okonite.com Los Angeles District Office (562) 590-3070 Fax: (562) 590-3139 E-Mail: losangeles@okonite.com

(763) 432-3818 FAX: (763) 432-3811 E-Mail: minneapolis@okonite.com New Orleans District Office and Service Center (504) 467-1920 FAX: (504) 467-1926 E-Mail: neworleans@okonite.com New York District Office NJ (973) 742-8040 NY (212) 239-0660 FAX: (973) 742-2156 E-Mail: newyork@okonite.com Philadelphia District Office (856) 931-0595 (215) 567-5739 FAX: (856) 931-1193 E-Mail: philadelphia@okonite.com **Phoenix District Office** (480) 838-8596 FAX: (480) 897-8924 E-Mail: phoenix@okonite.com Pittsburgh Service Center (724) 899-4300 FAX: (724) 899-4320 E-Mail: pittsburgh@okonite.com Portland District Office & Service Center (503) 598-0598 FAX: (503) 620-7447 E-Mail: portland@okonite.com Salt Lake District Office (801) 262-1993 FAX: (801) 262-3167 E-Mail: saltlake@okonite.com San Francisco District Office (925) 830-0801 FAX: (925) 830-0954 E-Mail: sanfrancisco@okonite.com Tampa District Office (813) 627-9400 FAX: (813) 246-4705 E-Mail: tampa@okonite.com Washington District Office (703) 904-9494 FAX: (703) 904-1610 E-Mail: washington@okonite.com International Sales (201) 825-0300 FAX: (201) 825-9026 E-Mail: ramsey@okonite.com

Minneapolis District Office













New Orleans, LA



Portland, OR



Ramsey, NJ





05684



# SUBSTATION **CONTROL CABLES**



Setting the Standard in Quality Since 1878

## **APPLICATION**

Utility substation control cables are multiconductor cables used to transmit low voltage and low current signals between the various electrical components (e. g. current transformers, relays, alarms, and monitoring equipment) in a substation. The signals can be analog or digital, continuous or intermittent.

Substation control cables are generally terminated in cabinets and the utilization equipment. They are often installed in cable trays, wireways, conduits, duct banks & trenches. These cables are suitable for wet or dry locations. Ambients are typically assumed to be 40°C air and 20°C earth.

Substation control cables can be rated 90°C or 75°C for wet and dry applications. Most substation cables have a -25°C installation temperature, but cables can be designed for -40°C installation applications, also.

Substation control cables can be shielded or unshielded. Shielded cables are used when shielding from ambient electrical interference is required. Typically shielded control cables are utilized in 230kV and above substations or, at lower voltages, where requirements dictate the need. High voltage transients could cause erroneous operation of or damage to equipment. Properly grounded shields help mitigate these types of occurrences.

The lower the shield resistance the more effective the shielding. Shields are typically a helically applied overlapped copper tape or a longitudinally applied overlapped copper tape. Sometimes the tape is supplemented with a bare copper grounding conductor.

Depending upon how these cables are installed, substation control cables are often required to pass a vertical tray flame test.



Contact your Okonite Sales Rep. who can assist you along with our staff of Application Engineers.



### **INDUSTRY STANDARDS**

Okonite can manufacture cables to the following industry standards:

- ICEA S-73-532/NEMA WC57: Standard for control cables.
- ICEA S-95-658/NEMA WC70: Standard for power cables rated 2000V or less for distribution of electrical energy.
- UL 1277: Standard for electrical power and control tray cables with optional fiber members.

#### **FLAME TEST RATINGS**

The following flame test ratings can be provided on Okonite substation cables:

- IFFF 383-74
- IEEE 1202

### **CABLE DESIGN CONSIDERATIONS**

- Conductor: Bare or tinned copper stranded conductors, Class B or C
- Insulation Color Code: ICEA methods 1 to 4.
- Grounding Conductor.
- Insulation: EPR, XLPE, PE/PVC.
- Voltage Ratings: 600V 1000V.
- Shielding: Helically applied copper tape, longitudinal corrugated copper tape, bare or tinned.
- Jacket Rip Cord.
- Overall Jacket: PVC, FR PVC, TP-CPE, TS-CPE, LSZH (TPPO, XLPO).

![](_page_1_Picture_28.jpeg)

![](_page_1_Picture_30.jpeg)

![](_page_1_Picture_32.jpeg)

![](_page_1_Picture_34.jpeg)

![](_page_1_Picture_35.jpeg)

![](_page_1_Picture_36.jpeg)